

Email: contact@winnipegairtesting.com

Take Home Asbestos Air Sampling Kit

The take home asbestos kit is an easy and inexpensive way to collect an asbestos air sample in your home. The kit contains everything you need to collect a sample and testing can be done in less than 45 minutes. The method counts all fibres including asbestos fibres.

The cost of the Take Home Asbestos Air Sampling Kit is \$120.00. This price includes:

- Kit rental (air pump, stand, timer, instructions)
- 1 air cassette and analysis
- Written report of findings

Additional samples can be added for \$60.00/sample.

Normal turnaround time for analysis is 3 business days. Next day analysis can be done for an extra \$60.00 per sample. The GST is added to all services.

Sampling Instructions

- 1. Plug air pump into a wall outlet.
- 2. Set up the metal tripod to around waist-height.
- 3. Take the clear rubber hose attached to the air pump and thread the free end through the loop on top of the tripod.
- 4. Label the black cassette with the sample location (ex. Bob's Office, Living Room).
- 5. Remove the stopper from the small opening on the top of the cassette.
- 6. Remove the bottom section of the cassette so it is fully open at the bottom (see image on right).
- 7. Attach the free end of the rubber hose to the small opening on the top of the cassette. (The hose will only attach to one end of the cassette when the bottom section is removed).
 - a. The cassette should hang down like in the top image. You are now ready to take the sample.
- 8. Start the pump by using the switch on the side of the pump.
- 9. Let the pump run for 30 minutes.
- 10. After 30 minutes, stop the pump.
- 11. Replace the clear stopper and the bottom section to seal the cassette.
- 12. Repeat steps 1-11 in all desired sampling locations.
- 13. Pack all equipment back into the testing case and return kit to Winnipeg Air Testing.

